

MOGOBIKE

Mirror Installation



1. Remove the mirrors from packaging.



2. Remove the wingnuts. You may need to use pliers.



3. Screw on the mirrors by placing the mirror assembly onto the bolt and turn.



4. If necessary, use a little force when screwing on the mirrors by pressing down firmly while turning.



5. Using an Allen wrench, tighten down the bolt.



You can adjust the swivel on the mirrors by using a small Allen wrench as shown above.